

Toshiba Strata DK Telephone System

Changing the time on a Strata DK system must be done from the "main" or primary phone. It is usually extension # 10, or # 200.

1. With the phone on-hook, dial intercom, #, 652 (depending on the system type, the # may or may not apply)
2. Enter the correct time using HH/MM/SS, like 07:24:00
3. Press redial

Comdial DX-80 System

Changing the time on a Comdial DX-80 system can be done from any display phone.

1. Press Feature # * and enter in your password (Default password #####)
2. Press Show and enter 0803
3. Press Save then Show
4. The option to change the Year will appear - if you do not need to change the year, press Next - if you need to change this value, press Chg, enter in two digits for the year and press Save then Next
5. The option to change the Month will appear - if you do not need to change the month, press Next - if you need to change this value, press Chg, enter in two digits for the month and press Save then Next
6. The option to change the Day will appear - if you do not need to change the date, press Next - if you need to change this value, press Chg, enter in two digits for the date and press Save then Next
7. The option to change the Weekday will appear - if you do not need to change the weekday, press Next - if you need to change this value, press Chg, to select the weekday, and press Next
8. The option to change the Hour will appear - press Chg and enter in two digits for the hour in military format - press Save then Next
9. The option to change the Minutes will appear - press Chg and enter in two digits for the minutes and press Save
10. Press the Hold button to exit programming mode

TOSHIBA 16

Leave the handset on hook, press intercom 6 5 2, then enter the time of a 24 hour clock, entering 2 digits for the hour, 2 digits for the minutes, and 2 digits for the seconds enter a leading 0 for any single digit entered, press Redial, press Speaker. This must be done at extension 10 usually the receptionist phone. For example, if the time is 2:15 P.M., press intercom 6 5 2, 1 4 1 5 0 0, Redial Speaker. .

TOSHIBA 16E / 40

Leave the handset on hook, press intercom # 6 5 2, then enter the time of a 24 hour clock, entering 2 digits for the hour, 2 digits for the minutes, and 2 digits for the seconds enter a leading 0 for any single digit entered, press Redial, press Speaker. This must be done at extension 10 usually the receptionist phone. For example, if the time is 2:15 P.M., press intercom # 6 5 2, 1 4 1 5 0 0, Redial Speaker.

TOSHIBA 280 / 424

Leave the handset on hook, press intercom # 6 5 2, then enter the time of a 24 hour clock, entering 2 digits for the hour, 2 digits for the minutes, and 2 digits for the seconds enter a leading 0 for any single digit entered, press Redial, press Speaker.

This must be done at extension 200 usually the receptionist phone. For example, if the time is 2:15 P.M., press intercom # 6 5 2, 1 4 1 5 0 0, Redial Speaker.

TOSHIBA CTX 100

Do Not Pick Up Handset (Must be done at display phone)

- Press Hold Button * # * # 1 * 2 * 3 *
- Display says Password =
- Enter 0 0 0 0
- Press HOLD Button
- Display says Prog =
- Enter 9 0 2
- Press HOLD
- Display says Select Param

To change Date:

- Press Intercom Button
- Enter Date: YY MM DD (YY=02, MM=10, DD=28)
- Press HOLD Button
- Press HOLD
- Lift Handset and return to cradle

To change Time:

- Press Line 1 button (button directly above intercom button)
- Enter Time: HH MM SS (HH=22 MM=03 SS=00) - military time must be used
- Press HOLD
- Press HOLD
- Lift handset and return to cradle

Toshiba DK280

Date

- From receptionist station, without lifting the handset, press "Intercom"
- Dial "#651"
- Dial the time in YY:MM:DD format.
- Press "Redial" or "#".
- Press speaker.

Time

- From receptionist station, without lifting the handset, press "Intercom"
- Dial "#652"
- Dial the time in military format HH:MM:SS.
- Press "Redial" or "#".
- Press speaker.

Day of the Week

- From receptionist station, without lifting the handset, press "Intercom"
- Dial "#653"
- Dial the day of the week (1-7).
- Press "Redial" or "#".

- Press speaker.

Toshiba Perception System - from attendant station

Follow all steps even if you wish to change only the time on your system.

Display Date:

- Press the "DIS TOD" key.
- The date is now displayed as follows:
SRC cos DEST
Month Day Year

Set Date:

Enter the date on the dial pad in MMDDYY format. The new date is displayed.

Display Time:

- Press the "DIS TOD" key again.
- The time is now displayed as follows:
SRC cos DEST
Hours Minutes Seconds

Set Time:

Enter the time in military time HHMMSS format (for example, 090105 for 9:01 am and 5 seconds and 210105 for 9:01pm and 5 seconds). The new time is displayed.

To Start the Clock and Clear Display:

Press the "DIS TOD" key a third time.