

Vodavi Starplus STS System

System Time/Date must be set by the first programmed Attendant via admin programming or using feature code 692.

To set using the feature code:

1. Dial [692] on the dial pad. A confirmation tone will sound.
2. Enter date and time as follows: YYMMDDHHMM
3. YY = Year (00-99)
4. MM = Month (01-12)
5. DD = Day (01-31)
6. HH = Hour (00-23)
7. MM = Minute (00-59)
8. When the correct number of digits are entered, a confirmation tone will sound.
9. Press the ON/OFF button to OFF to update the display.